□□□□□□□□□□□□ Punch □□□□□□□□□□□□□□□□□ PY-S880

□□□□□□□□□□□□□:

□□□□ □□□□□□	10000
□□□□□□□□□□□□□□□□□	50000
□□□□□□□□□□□□□□□□□□	ZEM510
□□□□□□□□□□	RS232 / 485, TCP / IP, USB □□□□□□□
□□□□□□□□□□□□□□□□	Workcode SMS, DLST □□□□□□□□□□□□□□□□□□□□□□ Self-Service, Switch □□□□□□□□□□□□□□□□□□□□□□□□□ T9 □□□-ID, □□□□□□□□□□□□□□□□□□□□□
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	3□ □□□□□□□□□□□□□□□□□□□□□□□□□□, □□□□□□□□, □□□□, Door Bell
Wiegand □□□□□□	□□□□□□□□□□ & amp; □□□□□□□□
□□□□□□□□□□□□□□□□□□□	□□□□□□□ / IC, Wi-Fi, GPRS
□□□□	3.5 □□□□□□□□□□ TFT
□□□□□□□□□□□□□□□	12V DC 1.5A
□□□□□□□□□□□□□□□□□□	0 ℃ - 45 ℃
□□□□□□□□□□□□□□□□□□	20% -80%

Packing list
For time attendance device:
In addition to the device, this package includes the following items:
Printed documentation and software CD
AC adapter
Accessory package
ID card (only for device with RFID function)
For access control device:
In addition to the device, this package includes the following items:
Printed documentation and software CD
Accessory package
ID card (only for the device with RFID function)
Contents may vary depending on the device configuration.


TCP/IP
PC
RS232/485 Switch
USB
iclock680
Printer